

Check RAM

If you have multiple Pis that you're using and moving around a lot, you might forget how much RAM your Pi has. If you forget, enter this in the terminal:

```
free -h
```

Revision #1

Created 3 December 2021 00:07:27 by DB T3CH

Updated 3 December 2021 00:08:16 by DB T3CH